


**LC95 Recumbent  
General Assembly**

**LC95R-0100-30**



DESCRIPTION	PART NUMBER
Installation Instructions	M051-00K20-B155
Operation Manual	M051-00K20-B125
Service Manual	M051-00K51-D008
Bag Assembly	AK51-00017-0000

**LC95 Recumbent  
Console Assembly**



**LC95R-0100-30**

Display Console

- AK51-00087-0001(R) Eng/Met
- AK51-00087-0003 Ger/Met
- AK51-00087-0004 Spn/Eur
- AK51-00087-0005 Spn/Met
- AK51-00087-0006 Jap/Met
- AK51-00087-0007 Frn/Eur
- AK51-00087-0008 Itl/Met
- AK51-00087-0009 Dut/Met
- AK51-00087-0010 Frn/Met

Overlay Bezel


- SK51-00093-0001Eng/Met
- AK51-00093-0003 Ger/Met
- AK51-00093-0004 Spn/Eur
- AK51-00093-0005 Spn/Met
- AK51-00093-0007 Frn/Eur
- AK51-00093-0008 Itl/Met
- AK51-00093-0009 Dut/Met
- AK51-00093-0010 Frn/Met



Console Case (Black)  
OK36-01187-0008

Screw  
0017-00101-0393


Battery Cover  
OK36-01035-0006



Screw  
0017-00101-0823 (4)


# LC95 Recumbent Frame Components - Right Side

LC95R-0100-30




# LC95 Recumbent Frame Components - Left Side

LC95R-0100-30




# LC95 Recumbent Extrusion Tube

LC95R-0100-30



**LC95 Recumbent  
Crank Arm Assembly**


**LC95R-0100-30**




NOTE: Order Crank Bearing Kit GK51-00002-0001

**LC95 Recumbent  
Stabilizer Bar Assembly**

**LC95R-0100-30**









**LC95 Recumbent  
Seat Assembly AK51-00011-0000**

**LC95R-0100-30**




**LC95 Recumbent  
Lock Assembly AK51-00053-0000**

**LC95R-0100-30**




**LC95 Recumbent**  
**Idler Pulley Assembly AK51-00089-0001**


**LC95R-0100-30**



# LC95 Recumbent Pulley Clutch Assembly

LC95R-0100-30






Shroud w/ Decal(RT)  
AK51-00083-0001  
Shroud Decal(RT)  
OK51-01041-0000

Shroud w/ Decal(LT)  
aK51-00083-0002  
Shroud Decal(LT)  
OK51-01041-0000


Shroud Screw(11)  
0017-00101-0991



# LC95 Recumbent Cables

# LC95R-0100-30

Polar Cable  
AK36-00021-00002



Console Cable  
AK51-00013-0000

Alternator Cable  
AK51-00019-0000

Cable Electrodes  
AK19-00077-0001

Heart Rate Cable  
AK19-00081-0001

Flat-Flex Cable  
AK19-00082-0001